



Dimension: 1.77" w x 0.28" h

V-T-14

WATERPROOF T-MOLDING

Used to fill the gap between two floors of equal height.

Used with floors ranging from 2-6mm in height.

Surface: Wear resistant
Core Material: Rigid PVC

1

1 1/8"

Floor

Subfloor

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

2

Measure and trim to fit.

3

1/4"

1/4"

Floor

Subfloor

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with construction adhesive).

4

Floor

Subfloor

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.