



BASEBOARD MOULDING INSTALLATION

1. Measure and cut your moulding using miter saw (*for best results we recommend using a power miter saw with a 10" - 80 tooth blade*). If you encounter an odd angle (non 90°), use a digital angle finder or experiment with a piece of scrap moulding to determine the appropriate angle.
2. Nail the moulding to the wall studs using a pneumatic nail gun or by drilling a hole through the moulding and counter sinking the nail.
3. Touch up the holes using a matching Color Stick™. Fill any gaps between the wall and moulding with a paintable caulk. Let it dry completely before painting the wall.

Tip: *Install door casing before installing base moulding.*