

Tools Typically Required:

Tissue paper.

Safety Precautions:

Apply in a well ventilated area. Wear gloves.

Preparation:

Surfaces must be clean, close fitting with no gaps, dry and free from oil, wax and paint. Protect work area. Lightly roughen smooth surfaces for better adhesion. Pre-fit parts to be joined.

Application:

To puncture the nozzle, turn cap clockwise continuously into the base until the clicking sound stops. Unscrew the cap counter clockwise to open the bottle. Squeeze the green side grips to dispense the adhesive. Apply the adhesive sparingly to one side only using approximately one drop per square inch of surface. Press surfaces together immediately and hold for 15-30 seconds. Do not attempt to reposition the parts. Immediately after use, clean tip with tissue and replace cap. For increased strength, leave the parts undisturbed for at least 5 minutes. Full cure in 24 hours.

Clean-up

After cleaning, wet any tissue used for wiping off glue with water and dispose of. When cleaning up larger quantities of uncured adhesive, apply water and allow to cure and then scrape up. Note this may result in damage to the surfaces. Cured adhesive may be cut away with caution using a sharp blade, removed with acetone or with boiling water. Note: Acetone is highly flammable and may not be suitable for use on all materials, test surface first. Follow manufacturer's instructions.