

REPLACEMENT PARTS

Take the replacement parts of CHFP-50B for example.

Contact your dealer or the factory for questions concerning prices and policies on replacement parts. Normally all parts can be ordered through your Authorized dealer/distributor.

FOR WARRANTY REPLACEMENT PARTS, A PHOTOCOPY OF THE ORIGINAL INVOICE WILL BE REQUIRED TO HONOR THE CLAIM.

When ordering replacement parts always give the following information:

- Model & Serial Number of appliance
- Installation date of appliance
- Part number
- Finish
- Description of part

⚠ WARNING

FAILURE TO POSITION THE PARTS
IN ACCORDANCE WITH THIS
MANUAL OR FAILURE TO USE ONLY
PARTS SPECIFICALLY APPROVED
WITH THIS APPLIANCE MAY
RESULT IN PROPERTY DAMAGE OR
PERSONAL INJURY.

*** IDENTIFIES ITEMS WHICH ARE NOT ILLUSTRATED. FOR FURTHER INFORMATION, CONTACT YOUR AUTHORIZED DEALER.**

For aftermarket sales and service please call 1-800-306-3829

COMPONENTS		
REF NO.	PART NO.	DESCRIPTION
1	CHP-001	LED CIRCUIT BOARD FOR EMBER BED
2	CHP-002	CIRCUIT BOARD
3	CHP-003	BLOWER AND HEATER ASSEMBLY
4	CHP-004	REMOTE CONTROL
5	CHP-005	STAND
6	CHP-006	FRONT GLASS
7	CHP-007	MIRROR GLASS
8	CHP-008	TRANSFORMER
9	CHP-009	REFLECTOR
10	CHP-010	REMOTE RECEIVER
11	CHP-011	BRACKET
12	CHP-012	FUSE
13	CHP-013	BACKLIGHT

NOTE: Care must be taken when removing and disposing of any broken glass or damaged components. Be sure to vacuum up any broken glass from inside the appliance before operation.

