



OPERATING INSTRUCTIONS

All of the following should be done with clean hands.

1. Remove Long Life Replacement Filter from plastic wrap.
2. Soak the long-life filter in cold tap water for 30 minutes before using.
3. Once filter has soaked for 30 minutes, flush the filter under the tap for 30 seconds and shake gently.

UPPER CHAMBER ASSEMBLY OF YOUR GWF8L

1. When replacing the long-life filter, you should wash and rinse out the entire water filtration system.
2. Align the two ports and locking tabs at the bottom of the pre-filter with the holes in the upper chamber of the filtration system and snap it into place.
3. Twist the soaked filter onto the base of the upper chamber of the filtration system. **Securely tighten the filter to the housing to make a tight seal for effective filtration.**
4. Re-attach lid to ring on the upper chamber.
5. You can now place your assembled upper chamber on top of the lower chamber.



MANUAL FILTER CHANGE REMINDER

To use the manual filter change reminder, turn the dial on the lid until the number in the green circle coincides with the month that the filter is being installed. The number that appears in the red circle will be the month to replace your filter. Repeat above step for every filter change.

HELPFUL TIPS

1. Keep your water filtration system in a dry place and out of direct sunlight.
2. Your Vitapur® Long Life Replacement Filter will last up to 4 months and filter over 379 liters (100 gallons) of water.
3. If the water filtration system has not been used for an extended period of time, please replace the long-life filter and wash top and bottom chambers.
4. When replacing the long-life filter, you should wash and rinse out the entire water filtration system.
5. Use only Vitapur® approved Long Life Replacement Filters (GWF3L).

Visit www.ghpgroupinc.com



Tested and certified by WQA to the requirements of NSF/ANSI standard 42 and 53 for the reduction of VOC, lead, chlorine, taste and odor.



www.ghpgroupinc.com
Customer service: 1-877-447-4768

NETTOYAGE INITIAL

Avec les mains propres:

1. Enlever le Filtre de Remplacement à Longue Duration de l'embellage plastique.
2. Laissez tremper le Filtre de Remplacement à Longue Duration dans l'eau froide du robinet environ 30 minutes avant de la mettre en place.
3. Rincer le filtre sous le robinet pendant 30 secondes avant installer.

CHAMBRE SUPÉRIEURE DE VOTRE GWF8L

1. Chaque fois que vous remplacez le filtre, profitez-en pour laver et rincer votre Système Vitapur®.
2. Alignez les deux tiges du fond du pré-filtre avec les deux orifices du bac supérieur et avec un coup sec mettez-le en place.
3. Vissez le filtre imbibé sur la base du compartiment supérieure du système de filtration. **Bien serrer le filtre pour faire un joint étanche pour une filtration efficace.**
4. Rassemblé le couvercle et rondelle
5. Vous pouvez maintenant placer votre bac supérieur sur le dessus du bac inférieur.



RAPPEL MANUEL DE CHANGEMENT DE FILTRE

Pour utiliser le rappel manuel de changement de filtre, tournez le bouton sur le couvercle à ce que le nombre dans le cercle vert coïncide avec le mois que le filtre est installé. Le numéro qui apparaît dans le cercle rouge sera le mois de remplacer votre filtre. Répétez ces procédures après le filtre a été changé.

CONSEILS UTILES

1. Placez le système de filtration dans un endroit sec et hors des rayons du soleil.
2. Votre Filtre à Longue Duration Vitapur® a une durée de 4 mois et filtre environ 379 litres (100 gallons) d'eau.
3. Si le système de filtration d'eau n'a pas été utilisé pendant une longue période de temps, s'il vous plaît remplacer le filtre et laver les compartiments supérieurs et inférieurs.
4. Chaque fois que vous remplacez le filtre, profitez-en pour laver et rincer votre Système Vitapur®.
5. Utilisez seulement des Filtres de Remplacements à Longue Duration approuvés par Vitapur® (GWF3L).

Disponible en ligne au www.ghpgroupinc.com



Testé et certifié par WQA conforme aux normes 42 et 53 de NSF/ANSI pour la réduction de COV, plomb, chlore, goût et odeur.



www.ghpgroupinc.com

Service à la Clientèle : 1-877-447-4768