

Save Money • Conserve Energy • Improve Efficiency


Reduce heat loss by as much as 90% • Quick & easy to install



The images shown are for visual reference only, follow manufacture guidelines per owners manual.

IMPORTANT:

Always keep mesh panels closed and glass doors **OPEN** when fire is burning in the fireplace.



1. **For masonry fireplaces only – not prefabricated.**

This firescreen is designed to surface mount on the outside of the fireplace.

2. Measure the width and height of your fireplace opening to the nearest 1/8".
3. Select the required size based on the glass firescreen sizing chart.

Size	Fits Opening		Overall Dimensions
	Width	Height	
Small	30" - 37"	22-1/2" - 29-1/2"	37-1/2" W x 30" H
Medium	30" - 37"	25-1/2" - 32-1/2"	37-1/2" W x 33" H
Large	36" - 43"	25-1/2" - 32-1/2"	43-1/2" W x 33" H