



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

- Choose desired installation height from any combination of stems provided.
NOTE: Additional stems can be added to increase installed height. Do not add more stems than will allow 6" (152mm) of fixture wire above canopy. Thread fixture wire thru each stem to be used. Screw stems together until secure. **NOTE:** Fixture can be installed directly into swivel for a semi-flush installation.
- Thread fixture wire through swivel and canopy. Screw end of stem assembly into swivel until secure.
- Measure 6" (152mm) of wire from end of canopy and cut off remaining wire. Separate wires and strip off 3/4" (19mm) of insulation from each end.
- If you are replacing an existing fixture, disconnect and remove the old fixture. Expose wiring from ceiling outlet box.
- Thread machine screws into the opposite end of the round mounting plate from the green ground screw. Lock the machine screws into place with hex nuts.
- Fasten the mounting plate to the outlet box using the two screws supplied with the outlet box.
- Spread the electrical wires so that the black wires are on one side of the outlet box and the white wires are on the other side.
- Grounding Instructions:**
Fixture is provided with ground wire. Connect fixture ground wire to ground wire from outlet box with wire connector.
Never connect ground wire to black or white power supply wires.
- To make electrical connections: Connect the white wire(s) from the fixture to the white wire of the outlet box with wire connector. Connect the black wire(s) from the fixture to the black wire of the outlet box with wire connector. **NOTE:** Black, outlet box wire may be red, round & smooth and/or have copper conductor. White outlet box wire may, be square & ridged and/or have a silver conductor.
- Place canopy against mounting surface allowing the machine screws to pass through the canopy. Secure with ball cap nuts.
- Install shade into fitter by tightening with counter ring.
- Install light bulb (not included)
FLUSH MOUNT INSTALLATION (without stems): Use type A 60 Watt maximum of medium base bulb
STEM HUNG INSTALLATION: Use type A 100 Watt maximum of medium base bulb

PORTFOLIO®