Mobile Home Skirting Installation Guide



Durakwik Stone is a great option for mobile home skirting. It has great features like realistic appearance, light weight and easy to work with. When compared to the vinyl siding, Durakwik Stone can provide the home with a much more premium look without breaking your budget

Underpining and Framing



1）Install concrete form sticks and install treated 2X4" onto sticks



2）Install untreated 2X4" horizontally along the bottom edge of the home



3）Install untreated 2X3" onto the 2X4"



4）Install treated plywood board. (Or install 2X4" vertically every 3'）

Installing Panels and Sills



1）Measure to determine panel qty and bottom raw height



2）Install bottom row starting from corner (cut panel to fit height)



3）Install next row up starting from corner



4）Install sill cap

Making access door



1）Cut the plywood board to size



2）Install cut panel and sill



3）Fit the door, make adjustment if needed



4）Apply touchup paint to cut surface