

**SPECIFICATIONS – BIRD-B-GONE POLYCARBONATE BIRD
SPIKE™**

PART 1 – GENERAL

1.1 SUMMARY

- A. Design Requirements: Select appropriate size and system as determined by site conditions to prevent birds from landing and roosting on specified surfaces.

1.2 QUALITY ASSURANCE

- A. Single Source responsibility: Furnish products from one manufacturer for entire project.
- B. Obtain all technical information from the manufacturer.
- C. Utilize labor or Bird-B-Gone Authorized Installers who are knowledgeable in Bird-B-Gone, Inc. product installations.
- D. Installer shall visit the site to gather all information of existing site conditions.

1.3 SUBMITTALS

- A. Product Data: Submit manufacturer's descriptive literature and product specifications for each product including catalogs, installation instructions other descriptive material.
- B. Provide Warranty on Material and Installation.
- C. Provide samples of each type of spike excluding proposed fastening methods.
- D. Provide statement by official indicating that they are a certified installation company.

1.4 PRODUCT HANDLING

- A. Protect Bird-B-Gone, Inc. products from damage before, during and after the installation.

1.5 PROJECT CONDITIONS

- A. Coordination: Furnish samples of system(s) so installation can be coordinated with existing conditions and within on-site conditions.
- B. Visit site and field measure prior to fabrication and delivery of materials.

1.6 WARRANTY

11/21/2006

- A. Product shall carry a minimum 5-year guarantee against U.V. breakdown.
- B. Installation shall be guaranteed for 2 years.

PART 2 – PRODUCTS

2.1 ACCEPTABLE MANUFACTURER

Manufacturer:

Bird-B-Gone, Inc.
Bird-B-Gone Polycarbonate Bird Spike™
23918 Skyline
Mission Viejo, CA 92692
Tel: 800-392-6915 or 949-472-3122
Fax: 949-472-3116
P.O.C.: Bruce Donoho

2.2 PRODUCT DESCRIPTION

- A. Model Designation:
 - 1. Bird-B-Gone Polycarbonate - 3” , 5” or 7”
 - a. Width of Coverage:
 - i. Polycarbonate Spike-3: 1” – 5” widths
 - ii. Polycarbonate Spike-5: 5” – 7” widths
 - iii. Polycarbonate Spike 2000-7: 7” – 10” widths
 - b. Height: 4-1/2”
 - c. Base Strip: Flexible
 - i. “Glue trough” feature (underside) for ease of attachment with adhesive.
 - ii. Offset pre-drilled holes, for ease of attachment with screws and / or adhesive.
 - d. Length: 2 ft. sections
 - e. Packaging: 50ft. / Box; 25 - 2ft. sections / box.
 - f. Color: As designated by the project specifications.
 - g. Number of Rows: As determined by the manufacturer and based on project conditions.
 - h. Mounting System: As determined by the manufacturer and based on project conditions.

2.3 MATERIALS

- A. Material: U.V. Stabilized Polycarbonate. Heat and weather resistant (+310 Deg. F. to –200 Deg. F.) Non-conductive and will not interfere with electronic security systems or transmissions.

11/21/2006

- B. Construction: Rigid one-Piece construction, available in 7 standard colors including crystal clear.
- C. Adaptation: "Break Away" points are located between each set of screw holes. Tin snips, hacksaw, etc. can also be used to cut the product to the desired length.

2.4 MOUNTING SYSTEMS

- A. Wood: Use #8 Wood Screws. For every 2 ft. Section of Bird Spike 2000™, ten (10) #8 wood screws are required.
- B. Steel, Brick, Stone or Concrete: Use an outdoor construction adhesive that is not silicone based. Purchase from the manufacturer or call for recommended adhesives. If mounting surface warrants, screw or bolt down Bird-B-Gone Polycarbonate Bird Spike in conjunction with using the adhesive.
- C. Pipes or Poles: Ty-Wraps can be used alone or in conjunction with an outdoor construction adhesive. For U.V. protected ty-wraps, purchase directly from the manufacturer or call for recommended products.

PART 3 – EXECUTION

3.1 EXAMINATION

- A. Examine the installation area and note any detrimental or hazardous work conditions. Notify contracting officer or inspector of the detrimental work conditions.
- B. Do not proceed with installation until conditions are corrected.

3.2 SURFACE PREPARATION

- A. Surface should be thoroughly cleaned and free of bird droppings, nesting materials, rust, peeling paint or other debris.
- B. Remove or repair articles that may damage Bird-B-Gone Polycarbonate Bird Spike after installation, including overhanging foliage, brush and loose parts on the structure.

3.3 INSTALLATION

- A. Install Bird-B-Gone Polycarbonate Bird Spike as recommended by the manufacturer.
- B. Bird-B-Gone Polycarbonate Bird Spike should be installed correctly, covering the entire depth of the surface, not just the perimeter.
 - 1. Follow the contours and angles closely: cut or break away to fit properly.

11/21/2006

2. Space materials in accordance with manufacturer's recommendations.

3.4 INSPECTION

- A. Visually inspect Bird-B-Gone Polycarbonate Bird Spike for any signs of poor installation, including loose screws, fasteners and un-removed debris.
- B. Immediately correct and repair as necessary.

END OF SPECIFICATONS